

# Melec



Stepping & Servo Motor Controller

## C-VX871E

### Instructions Manual (For designers' use)

# USER'S MANUAL

Please ensure to read and understand this Instructions Manual before using the Product. Please keep this Instructions Manual at hand so that it is always available for reference.

CE

MN0150

## Introduction

This instructions manual explains the handling of "Stepping Motor and Servo Motor Controller C-VX871E" emphasizing the specifications to enable proper and safe use.

The manual is thus intended for designers of control systems using stepping motors or servo motors.

Before using the product, read this manual carefully for better understanding.

Keep the manual handy so that you can read it whenever you want.

The C-VX871E allows axes to be controlled independently and therefore referred to each axis as follows:

Product Name	Number of axes	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis
C-VX871E	6 axes	X axis	Y axis	Z axis	A axis	B axis	C axis

This manual basically explains only the X axis.

## Description of Safety

This product must be handled correctly.

Handling the product incorrectly may cause unexpected accidents resulting in personal injuries or damage to your properties.

Many of those accidents can be avoided if you have advance information on dangerous situations.

This manual provides precautions where dangerous situations are predicted. The manual provides the following alert marking and messages for this purpose:



This indicates a hazardous situation that could result in death or serious personal injury if you do not perform the procedure correctly.



This indicates a potentially hazardous situation that could result in personal injury or physical damage if you do not perform the procedure correctly.

## Before Use

This product is not designed for use in the equipment related to nuclear power, aerospace equipment, vehicles, marine vessels, medical equipment directly in touch with human body, equipment anticipated to give a serious impact to properties, and other equipment required to provide high reliability.

Take failsafe measures so that the whole system operates safely even if the input power causes an error, a signal line is disconnected, or the main unit fails.

This product is equipped with a LIMIT (overtravel) signal and an FSSTOP signal to prevent mechanical damage.

The initial values of these signals are set to ACTIVE OFF (B contact). Accordingly, even in a system configuration in which the FSSTOP and LIMIT signals are not used, pulses are not output unless NORMAL ON (GND connection) is enabled.

Be sure to use this product within the scope of the specifications described in this instruction manual in accordance with the specification method described therein.

Set up the product before operating it.

Refer to Section 3, "Setting."

When board Controller (C-VX871E) is used on Windows, refer to separate manual "C-VX870 series Device Driver Manual (MN0105,MN0106)".

When board Controller (C-VX871E) is used on any OS other than Windows, refer to separate manual "Technical Data A. (MN0110)"

Introduction  
Description of Safety  
Before Use

# Contents

PAGE

## 1 . OVERVIEW

1-1.	Features .....	4
1-2.	Product Configuration .....	4
1-3.	Example of System Configuration .....	4
1-4.	Function Block Diagram .....	5
1-5.	Externals of product .....	6

## 2 . SPECIFICATIONS

2-1.	PCI Specifications .....	7
2-2.	General Specifications .....	7
2-3.	Basic Specifications .....	8
2-4.	Applied Functions .....	10
2-5.	Input and Output Signal Table .....	12
	(1) User I/O connector .....	12
	(2) Special-purpose I/O connector .....	14
2-6.	Input and Output Specifications .....	16
	(1) Output specifications .....	16
	(2) Input specifications .....	17
2-7.	Outside Dimensions .....	18

## 3 . SETTING

3-1.	Setting the Board Number(S1) .....	19
------	------------------------------------	----

## 4 . CONNECTION

4-1.	Example of user I/O Interface Power Supply Connection .....	20
4-2.	Examples of Connection to Drivers .....	21
	(1) Example of connection to the stepping motor driver .....	21
	(2) Example of connection to the servo motor driver .....	22
4-3.	Examples of Connection to Sensors .....	23
	(1) Example of sensor attachment (photosensor) .....	23
	(2) Example of connection to a limit sensor .....	23
	(3) Example of connection to an origin sensor .....	24

## 5 . Maintenance

5-1.	Maintenance and Inspection .....	26
	(1) Cleaning method .....	26
	(2) Inspection method .....	26
	(3) Replacement method .....	26
5-2.	Saving and Disposal .....	26
	(1) Saving method .....	26
	(2) Disposal method .....	26

## 6 . Conforming to Europe standards

6-1.	Low Voltage Directive .....	27
6-2.	EMC Directive .....	27

The main parts which revised by this manual

## 1 . OVERVIEW

### 1-1. Features

The C-VX871E is a controller equipped with six independently functioning axes.

This controller supports servo and stepping motors that can directly be inserted into slots of a PCI Express bus system(x1 Lane) conforming to PCI Express bus specifications R1.0a.

The board shape is the CEM (x1 Lane) short card size(107 x 170) of the PCI Express bus standard.

The C-VX871E is equipped with our chip controller MCC07 to enable motor control using simple commands.

C-VX871E enables six independently linear interpolation driving, 2-axis linear interpolation (fixed interpolation-axes) or 2-axis circular interpolation (fixed interpolation-axes) driving.

The 32-bit width address counter and the maximum output frequency of 6.5 MHz of the MCC07 enables high-precision, high-speed positioning.

The C-VX871E has equipped with a multi-functional 32-bit pulse counter.

The applications also include interrupt output and external signal output using the comparator function of each counter.


After the command being executed is finished, the commands stored in the reservation register are executed sequentially. Then this function can be allowed continuous drive. **(Applied function)**

The C-VX871E is enable to optional axes liner interpolation drive or Optional 2-axis circular interpolation drive. **(Applied function)**


### 1-2. Product Configuration

Product name	Rating	Maker	Quantity	Remarks
Controller	C-VX871E	Melec Inc.	1	(Main unit)

### 1-3. Example of System Configuration




#### 1-4. Function Block Diagram



- ① Bus interface block  
Interface block with the PCI Express bus  
The PCI Express is x1 lane.
- ② Drive control block  
The drive control block outputs serial pulses to the motor driver.  
The 2-axis indicated by    is interrelation.  
It enables 2-axis linear interpolation or 2-axis circular interpolation.
- ③ Counter block  
The counter block has three types of counters: ADDRESS COUNTER, PULSE COUNTER, and DFL COUNTER. (Can use as hard timer.)  
ADDRESS COUNTER, PULSE COUNTER has 32-bit counter, DFL COUNTER(Hard timer) has 16-bit counter. These counters count pulses output by the controller.  
Each counter equipped with three compare registers. These registers count optional count.
- ④ HARD CONFIGURATION block (APPLIED FUNCTION)  
The HARD CONFIGURATION block is a control block that allows the user to connect User I/O and Special-purpose I/O to signals: Multipurpose sensor signal input to each axis, signal for synchronization control, status signal.  
The control block is used for multipurpose sensor function, Synchronous drive function, Status output function.
- ⑤ User I/O block  
The user I/O block interfaces with motor drivers, and sensors equipment signals.
- ⑥ Special-purpose I/O block (APPLIED FUNCTION)  
The block interfaces with input signals what motors can be operated manually, and what can output status signals to the outside.

## 1-5. Externals of product



①CN1 ----- x1 lane board edge connector inserted into a PCI Express bus slot.

②J1 ----- 100-pin half pitch connector that interfaces the motor driver, sensor signals, and equipment having +24V interface I/O.  
Dedicated interface cables (1m, 2m, 3m, and 5m) and relay units are available.

③J3 ----- Connector that interfaces with external signals at TTL level.

(APPLIED FUNCTION) Motors can be operated by manual operation through this connector.  
External input signals can be assigned as input signals to signals for the SENSOR and signal for synchronization control.  
Signals can be output to the outside by status signal of each axis.  
A general-purpose standard MIL connector is used.

④S1 ----- Rotary switch that is set so that PCI can recognize the board number.

If two or more boards are inserted into the PC simultaneously, set the switch properly so that every board number is unique.

⑤RDY LED -- LEDs that allows the user to simply monitor the X, Y, Z, A, B and C axes to check whether the axes are operating normally. The RDY LED corresponding to each axis is on while the axis is waiting for a command and is off during command processing.

**2 . SPECIFICATIONS****2-1. PCI Specifications**

No.	Item	Specifications
1	Applicable standard	PCI Express Base Specification Rev1.0a
2	Bus interface	PCI Express x1 lane
3	Interrupt	INTA#
4	system resouce	I/O : 4K-byte
5	Dimensions	PCI Express CEM x1 short card size(107mm × 170mm × 17mm)

**2-2. General Specifications**

No.	Item	Specifications
1	Supply voltage, power consumption	<ul style="list-style-type: none"> <li>• +3.3V ± 9%, 1.6A or less</li> <li>• DC+24V ± 2V, 250mA or less (for photocoupler interface)</li> </ul>
2	Operating ambient temperature and humidity	<ul style="list-style-type: none"> <li>• 0 ~ +45</li> <li>• 80%RH or less (without dew condensation)</li> </ul>
3	Storage temperature and humidity	<ul style="list-style-type: none"> <li>• 0 ~ +55</li> <li>• 80%RH or less (without dew condensation)</li> </ul>
4	Installation environment	<ul style="list-style-type: none"> <li>• Inside a well-ventilated cabinet installed indoor, free from direct sunlight</li> <li>• Not exposed to corrosive and flammable gasses, and not affected by oil mist, dust, salt, iron powder, water, and chemicals</li> <li>• Not subject to constant vibration or excessive shock</li> <li>• Not affected by electromagnetic noise caused by power equipment</li> <li>• Free of radioactive materials and magnetic fields, and not in vacuum</li> </ul>
5	Weight	<ul style="list-style-type: none"> <li>• About 0.2 kg</li> </ul>

## 2-3. Basic Specifications

No.	Item	Specifications	
1	Number of control axes	6 axes	
2	Pulse output function	Output type	<ul style="list-style-type: none"> <li>• Independent direction output/Specified direction output/Phase-differential signal output</li> <li>• Line driver output</li> </ul>
		Output frequency	<ul style="list-style-type: none"> <li>• Independent drive : 0.1 Hz to 6.5 MHz</li> <li>• Interpolation drive : 0.1 Hz to 5 MHz</li> </ul>
		Acceleration/deceleration time constant	5000 ms/kHz to 0.0025 ms/kHz (Trapezoid/S-curve)
		Acceleration/deceleration shape	Trapezoid/S-curve(This feature enables to set asymmetrical shape)
		Triangular drive prevention function	<ul style="list-style-type: none"> <li>• During S-shaped acceleration/deceleration drive, INDEX drive may end before the maximum speed is reached. In this event, triangular drive can be automatically avoided.</li> </ul>
		Number of output pulses	<ul style="list-style-type: none"> <li>• JOG drive : -65,535 to +65,535 pulse</li> <li>• SCAN drive : Up to infinite pulses</li> <li>• INDEX drive : -2,147,483,647 to + 2,147,483,647 pulses</li> </ul>
3	Encoder function	None	
4	Drive function	JOG drive	<ul style="list-style-type: none"> <li>• Pulses are constantly output until the specified pulses.</li> </ul>
		SCAN drive	<ul style="list-style-type: none"> <li>• Pulses are continuously output until a stop command is detected.</li> </ul>
		INDEX drive	<ul style="list-style-type: none"> <li>• Pulses are output until the specified relative or absolute address is reached.</li> </ul>
		ORIGIN drive	<ul style="list-style-type: none"> <li>• The specified drive processes are performed. This drive is finished when the ORG signal specified edge is detected.</li> </ul>
		2-axis linear interpolation drive	<ul style="list-style-type: none"> <li>• Linear interpolation is performed toward the specified coordinates from the current coordinates.</li> <li>• Driving type is selected from INDEX drive or SCAN drive.</li> <li>• Max speed is 5MHz.</li> <li>• Positional errors for the specified straight line are <math>\pm 0.5</math> LSB.</li> <li>• The absolute and relative addresses that can be specified for coordinates range from -2,147,483,647 to +2,147,483,647 (32 bits).</li> </ul>
		2-axis circular interpolation drive	<ul style="list-style-type: none"> <li>• Circular interpolation is performed toward the specified coordinates from the current coordinates on the circular curve specified by the center-point or passing-point coordinates.</li> <li>• Driving type is selected from INDEX drive or SCAN drive.</li> <li>• Max speed is 5MHz.</li> <li>• Positional errors for the specified circuit curve are <math>\pm 1</math> LSB.</li> <li>• The relative addresses range from -8,388,607 to +8,388,607 (24 bits).</li> <li>• Short axis pulses range from -2,147,483,648 to +2,147,483,647 (32 bits).</li> </ul>
		Linear speed constant control	<ul style="list-style-type: none"> <li>• Control is performed to keep the synthesized speed of the two axes working for interpolation drive constant.</li> </ul>

No.	Item	Specifications	
5	Stop function	Slow stop function	<ul style="list-style-type: none"> <li>• SLOW STOP command</li> <li>• Detection of a match of the comparator of each counter.</li> <li>• Multipurpose sensor signal(SS0,SS1)</li> </ul>
		Immediate stop function	<ul style="list-style-type: none"> <li>• FAST STOP command</li> <li>• FSSTOP signal (User I/O)</li> <li>• FSSTOP signal (Special-purpose I/O)</li> <li>• Detection of a match of the comparator of each counter.</li> <li>• Multipurpose sensor signal(SS0,SS1)</li> </ul>
		LIMIT signal	<ul style="list-style-type: none"> <li>• + direction stop</li> <li>• Immediate stop by CWLM signal and slow stop can be selected.</li> <li>• Slow stop or immediate stop can be performed for each axis upon detection of a match of the comparator(COMP2) of each counter.</li> <li>• - direction stop</li> <li>• Immediate stop by CCWLM signal and slow stop can be selected.</li> <li>• Slow stop or immediate stop can be performed for each axis upon detection of a match of the comparator(COMP3) of each counter.</li> </ul>
6	Counter function	Address counter	<ul style="list-style-type: none"> <li>• 32-bit counter that manages absolute addresses by counting drive output pulses</li> </ul>
		Pulse counter	<ul style="list-style-type: none"> <li>• 32-bit counter that counts external pulse signals or encoder feedback pulses.</li> </ul>
		Pulse differential counter	<ul style="list-style-type: none"> <li>• It is a 16-bit counter which counts a drive pulse output or a system clock (20MHz). A standard clock is counted and it can be used as a timer.</li> <li>* Since this product has not equipped the encoder pulse input circuit, the deviation of a drive pulse output and an encoder pulse is undetectable.</li> </ul>
		Comparator function	<ul style="list-style-type: none"> <li>• Detection of a match of the three comparators of each counter.</li> <li>• Upon detection of a match by the comparator, pulse output can be decelerated and then stopped, or stopped immediately.</li> <li>• Upon detection of a match by the comparator, output external status signal.</li> </ul>
		AUTO CLEAR function	<ul style="list-style-type: none"> <li>• The comparator of each counter:The counter can automatically be cleared upon detection of a match of COMP1 of each counter.</li> </ul>
		AUTO ADD function	<ul style="list-style-type: none"> <li>• The comparator of each counter:If the counter value reaches the COMP1, a value that is set by the data add to COMPARE REGISTER1.</li> </ul>
7	Other functions	Servo driver support function	<ul style="list-style-type: none"> <li>• The signals are specially prepared as servo driver support signals.</li> <li>• Servo positioning completion input/phase (<math>\overline{\text{DEND}}/\overline{\text{PO}}</math>) signal input</li> <li>• Servo reset output (<math>\overline{\text{DRST}}</math>)</li> </ul>
		Data reading function	<ul style="list-style-type: none"> <li>• Current status information can be read in real time. Current status information includes status data, count data of a counter etc.</li> </ul>

## 2-4. Applied Functions

No.	Item	Description of specifications	
1	Drive function	UP/DOWN/CONST drive CHANGE function	• Drive change for acceleration, deceleration, or constant speed can be performed upon detection of signal at an arbitrary change operation point.
		SPEED CHANGE function	• The drive pulse speed is changed upon detection of signal at an arbitrary change operation point.
		RATE CHANGE function	• The rate is changed upon detection of signal at an arbitrary change to the specified rate.
		INDEX CHANGE function	<ul style="list-style-type: none"> <li>• Upon detection of signal at an arbitrary change operation point, the stop position at which drive is to be finished is changed.</li> <li>• Upon detection of the INC INDEX CHANGE command, the system performs INC INDEX drive by setting the specified data at the stop position of the relative address for which the start position is the origin.</li> <li>• Upon detection of the ABS INDEX CHANGE command, the system performs ABS INDEX drive by setting the specified data at the stop position of the absolute address managed with the address counter.</li> </ul>
		Optional axes liner interpolation drive	C-VX871 Linear interpolation is performed toward the specified coordinates from the current coordinates. Then long axis outputs pulses. C-VX873 Linear interpolation is performed toward the specified coordinates from the current coordinates. Then long axis outputs pulses. Optional axes are as follows: (First affiliated axis :X1 to C1 axis, Second affiliated axis:X2 to C2 axis)
		Optional 2-axis circular interpolation drive	C-VX871 Circular interpolation is performed toward the specified coordinates from the current coordinates on the circular curve. C-VX873 Circular interpolation is performed toward the specified coordinates from the current coordinates on the circular curve. Optional axes are as follows: (First affiliated axis :X1 to C1 axis, Second affiliated axis:X2 to C2 axis)
		INDEX drive control the start point at auto deceleration	• This function is allowed to set OFFSET of the start point at auto deceleration. This function can be used When INDEX drive, liner interpolation INDEX drive, and circular interpolation INDEX drive.
		MANUAL SCAN drive	• MANUAL SCAN/JOG drive in the + or - direction is performed by operation of SELA to D, $\overline{\text{MAN}}$ , $\overline{\text{CWMS}}$ , $\overline{\text{CCWMS}}$ signal input through the J3 connector.
2	Count function	Ring counter function	• The address counter, pulse counter each are a ring counter in which any maximum count can be set.
		Count data latch/clearance function	<ul style="list-style-type: none"> <li>• This function latches count data of a counter at a specific latch timing and holds it till the next latch timing.</li> <li>• Each counter can latch counter value at arbitrary timing. It is possible to clear a counter value at the latch timing.</li> </ul>

No.	Item	Description of specifications	
3	Other functions	Interrupt function	<ul style="list-style-type: none"> <li>• Each axis can output interrupt signals to the CPU.</li> <li>• Each interrupt signal is output when an interrupt is caused by drive end, state of a reservation register, and detection of a match by the counter.</li> </ul>
		Command reservation function	<ul style="list-style-type: none"> <li>• Each axis has a reservation register that can store data commands for ten instructions.</li> <li>• General-purpose commands of Drive commands can be reserved in the reservation register.</li> <li>• After the command being executed is finished, the commands stored in the reservation register are executed sequentially. Then this function can be allowed continuous drive.</li> </ul>
		Input signal logical switch function	<ul style="list-style-type: none"> <li>• The input signal can be changed to logic as follows:</li> <li>• CWLM</li> <li>• CCWLM</li> </ul>
		Input signal time constant function	<ul style="list-style-type: none"> <li>• The input signal can be set time constant as follows:</li> <li>• CWLM</li> <li>• CCWLM</li> <li>• <math>\overline{\text{DEND/PO}}</math></li> <li>• <math>\overline{\text{ORG}}</math></li> <li>• <math>\overline{\text{NORG}}</math></li> <li>• <math>\pm \text{ZORG}</math></li> </ul>
		Multipurpose sensor signal input	<p>Each axis has multipurpose sensor signal input used as stop signal, trigger signal of a counter latch data and drive CHANGE operating signal.</p> <p>The signal can be used as multipurpose sensor as follows:</p> <ul style="list-style-type: none"> <li>• <math>\overline{\text{SENSORx}}</math> input signal</li> <li>• <math>\overline{\text{SIGNAL INx}}</math> input signal</li> <li>• A status in any axis</li> </ul>
		Status external signal output function	<ul style="list-style-type: none"> <li>• The compare register value, STATUS, output signal of each counter can output as <math>\overline{\text{SIGNAL OUTx}}</math> output signal.</li> </ul>
		Synchronized start function	<ul style="list-style-type: none"> <li>• You can perform synchronized start with any axis.</li> <li>• A condition of start can be set by the condition as follows:</li> <li>• <math>\overline{\text{SENSORx}}</math> input signal</li> <li>• <math>\overline{\text{SIGNAL INx}}</math> input signal</li> <li>• A status in any axis</li> <li>• PAUSE command</li> </ul>
		Status read Data reading	<ul style="list-style-type: none"> <li>• Current status information can be read in real time.</li> <li>• Current status information includes setting data any axis, latch data of a counter etc.</li> </ul>


Applied function. Refer to the separate manual 「MPL-30/PCIW32 Applied Functions Part」

## 2-5. Input and Output Signal Table

### (1) User I/O connector

#### Pin assignments

- Connector type name : DX10A -100S(50) (HIROSE Electric)
- Adaptable socket : DX30A -100P(50) ,DX31A -100P etc.  
(Hirose Electric, not included in attached accessories)
- Adaptable cable : 1m , 2m, 3m, or 5m shielded cable (option)



#### Signal table

<b>CAUTION</b>	<p>This product may be damaged.</p> <p>Do not connect +24V to any pin other than EXTV.</p> <p>After wiring, be sure to confirm the wiring before power-on.</p>
----------------	--

A signal indicated by   is photocoupler-insulated.

A signal is enable to set time constants marked with   .(Applied function)

Logic switching is enabled for an input signal marked with   .(Applied function)

Logic switching is enabled for general-purpose input signal  $\overline{INx}$ ,  
when this signal is used for DALM function

#### (Note 1)

An external power supply is required for a signal that is photocoupler-insulated.

The specified input voltage range is +24V  $\pm$  2V.

Current consumption at +24V is up to 250mA.

The initial values of the CWLM and CCWLM signals of each axis and the FSSTOP signal are ACTIVE OFF input (B contact).

An external power supply must be connected even if these signals are not used.

The default contact B is recommended for the CWLM and CCWLM signals.

However, A-contact signal input can also be used by switching logic.

#### (Note 2)

$\overline{SENSORx}$  input signals are used for multipurpose sensor function, synchronization control function. These input signals is used by any functions setting.(Applied function)

The initial value after resetting is as follows:

$\overline{SENSOR0}$  signal is SS0 of Z axis,  $\overline{SENSOR1}$  signal is SS0 of A axis.

When  $\overline{SENSORx}$  input signal is used for multipurpose sensor function, this signal can not use in MANUAL mode.

When MANUAL mode, the functions of multipurpose sensor assigned to the  $\overline{SENSORx}$  input signal are invalid.

When BUS mode, this function are valid.


Pin No.	Direction	Signal name	Description	Pin No.	Direction	Signal name	Description
1	In	XCWLM	X axis + (CW) direction limit signal	51	In	ZCWLM	Z axis + (CW) direction limit signal
2	In	XCCWLM	X axis - (CCW) direction limit signal	52	In	ZCCWLM	Z axis - (CCW) direction limit signal
3	In	$\overline{\text{XNORG}}$	X axis machine origin proximity signal	53	In	$\overline{\text{ZNORG}}$	Z axis machine origin proximity signal
4	In	$\overline{\text{XORG}}$	X axis machine origin signal	54	In	$\overline{\text{ZORG}}$	Z axis machine origin signal
5	In	YCWLM	Y axis + (CW) direction limit signal	55	In	ACWLM	A axis + (CW) direction limit signal
6	In	YCCWLM	Y axis - (CCW) direction limit signal	56	In	ACCWLM	A axis - (CCW) direction limit signal
7	In	$\overline{\text{YNORG}}$	Y axis machine origin proximity signal	57	In	$\overline{\text{ANORG}}$	A axis machine origin proximity signal
8	In	$\overline{\text{YORG}}$	Y axis machine origin signal	58	In	$\overline{\text{AORG}}$	A axis machine origin signal
9	In	BCWLM	B axis + (CW) direction limit signal	59	In	CCWLM	C axis + (CW) direction limit signal
10	In	BCCWLM	B axis - (CCW) direction limit signal	60	In	CCCWLM	C axis - (CCW) direction limit signal
11	In	$\overline{\text{BNORG}}$	B axis machine origin proximity signal	61	In	$\overline{\text{CNORG}}$	C axis machine origin proximity signal
12	In	$\overline{\text{BORG}}$	B axis machine origin signal	62	In	$\overline{\text{CORG}}$	C axis machine origin signal
13	In	$\overline{\text{SENSOR0}}$	Multipurpose sensor, synchronous start signal (Note 2)	63	In	$\overline{\text{SENSOR1}}$	Multipurpose sensor, synchronous start signal (Note 2)
14	-	EXTV	External power supply for coupler (Note 1)	64	-	EXTVGND	External power supply for coupler GND (Note 1)
15	-	EXTV		65	-	EXTVGND	
16	-	N.C	Reserved	66	-	N.C	Reserved
17	Out	+COM	$\overline{\text{XCWP}}, \overline{\text{XCCWP}}$ +common (+5V)	67	Out	+COM	$\overline{\text{ZCWP}}, \overline{\text{ZCCWP}}$ +common (+5V)
18	Out	XCWP	X axis + (CW) direction positive logic pulse output	68	Out	ZCWP	Z axis + (CW) direction positive logic pulse output
19	Out	$\overline{\text{XCWP}}$	X axis + (CW) direction negative logic pulse output	69	Out	$\overline{\text{ZCWP}}$	Z axis + (CW) direction negative logic pulse output
20	Out	XCCWP	X axis - (CCW) direction positive logic pulse output	70	Out	ZCCWP	Z axis - (CCW) direction positive logic pulse output
21	Out	$\overline{\text{XCCWP}}$	X axis - (CCW) direction negative logic pulse output	71	Out	$\overline{\text{ZCCWP}}$	Z axis - (CCW) direction negative logic pulse output
22	Out	XDRSTCOM	XDRST current output (+24V)	72	Out	ZDRSTCOM	ZDRST current output (+24V)
23	Out	$\overline{\text{XDRST}}$	X axis servo reset signal (This signal is used for general purpose output)	73	Out	$\overline{\text{ZDRST}}$	Z axis servo reset signal (This signal is used for general purpose output)
24	In	$\overline{\text{XDEND/XPO}}$	X axis positioning completion signal /X axis P0 signal	74	In	$\overline{\text{ZDEND/ZPO}}$	Z axis positioning completion signal /Z axis P0 signal
25	In	+XZORG	X axis encoder +Z phase signal	75	In	+ZZORG	Z axis encoder +Z phase signal
26	In	-XZORG	X axis encoder -Z phase signal	76	In	-ZZORG	Z axis encoder -Z phase signal
27	Out	+COM	$\overline{\text{YCWP}}, \overline{\text{YCCWP}}$ +common (+5V)	77	Out	+COM	$\overline{\text{ACWP}}, \overline{\text{ACCWP}}$ +common (+5V)
28	Out	YCWP	Y axis + (CW) direction positive logic pulse output	78	Out	ACWP	A axis + (CW) direction positive logic pulse output
29	Out	$\overline{\text{YCWP}}$	Y axis + (CW) direction negative logic pulse output	79	Out	$\overline{\text{ACWP}}$	A axis + (CW) direction negative logic pulse output
30	Out	YCCWP	Y axis - (CCW) direction positive logic pulse output	80	Out	ACCWP	A axis - (CCW) direction positive logic pulse output
31	Out	$\overline{\text{YCCWP}}$	Y axis - (CCW) direction negative logic pulse output	81	Out	$\overline{\text{ACCWP}}$	A axis - (CCW) direction negative logic pulse output
32	Out	YDRSTCOM	YDRST current output (+24V)	82	Out	ADRSTCOM	ADRST current output (+24V)
33	Out	$\overline{\text{YDRST}}$	Y axis servo reset signal (This signal is used for general purpose output)	83	Out	$\overline{\text{ADRST}}$	A axis servo reset signal (This signal is used for general purpose output)
34	In	$\overline{\text{YDEND/YPO}}$	Y axis positioning completion signal /Y axis P0 signal	84	In	$\overline{\text{ADEND/APO}}$	A axis positioning completion signal /A axis P0 signal
35	In	+YZORG	Y axis encoder +Z phase signal	85	In	+AZORG	A axis encoder +Z phase signal
36	In	-YZORG	Y axis encoder -Z phase signal	86	In	-AZORG	A axis encoder -Z phase signal
37	Out	+COM	$\overline{\text{BCWP}}, \overline{\text{BCCWP}}$ +common (+5V)	87	Out	+COM	$\overline{\text{CCWP}}, \overline{\text{CCCWP}}$ +common (+5V)
38	Out	BCWP	B axis + (CW) direction positive logic pulse output	88	Out	CCWP	C axis + (CW) direction positive logic pulse output
39	Out	$\overline{\text{BCWP}}$	B axis + (CW) direction negative logic pulse output	89	Out	$\overline{\text{CCWP}}$	C axis + (CW) direction negative logic pulse output
40	Out	BCCWP	B axis - (CCW) direction positive logic pulse output	90	Out	CCCWP	C axis - (CCW) direction positive logic pulse output
41	Out	$\overline{\text{BCCWP}}$	B axis - (CCW) direction negative logic pulse output	91	Out	$\overline{\text{CCCWP}}$	C axis - (CCW) direction negative logic pulse output
42	Out	BDRSTCOM	BDRST current output (+24V)	92	Out	CDRSTCOM	CDRST current output (+24V)
43	Out	$\overline{\text{BDRST}}$	B axis servo reset signal (This signal is used for general purpose output)	93	Out	$\overline{\text{CDRST}}$	C axis servo reset signal (This signal is used for general purpose output)
44	In	$\overline{\text{BDEND/BPO}}$	B axis positioning completion signal /B axis P0 signal	94	In	$\overline{\text{CDEND/CPO}}$	C axis positioning completion signal /C axis P0 signal
45	In	+BZORG	B axis encoder +Z phase signal	95	In	+CZORG	C axis encoder +Z phase signal
46	In	-BZORG	B axis encoder -Z phase signal	96	In	-CZORG	C axis encoder -Z phase signal
47	In	FSSTOP	All axes immediate stop signal	97	In	$\overline{\text{RESET}}$	All-axis reset signal
48	-	N.C	Reserved	98	-	N.C	Reserved
49	-	N.C	Reserved	99	-	N.C	Reserved
50	-	D.GND	Internal +5V digital GND	100	-	D.GND	Internal +5V digital GND

## (2) Special-purpose I/O connector

The connector of the applied function.

### Pin assignment

- Connector type name : XG4C-2031 (OMRON)
- Adaptable connector socket : XG4M-2030 (OMRON, not included in attached accessories)
- Adaptable cable : MIL 20P 1.5m flat cable (option)



### Signal table

- All input signal is not able to set time constants, to switch logic.

(Note 1) When the  $\overline{\text{MAN}}$  signal goes low, this board is MANUAL mode.

When the  $\overline{\text{MAN}}$  signal goes high, this board return to BUS mode.

The  $\overline{\text{MAN RDY}}$  signal is enable to go high by MAN MASK command.

When the  $\overline{\text{MAN}}$  signal is low level, this board is not MANUAL mode by setting  $\overline{\text{MAN}}$  signal low level.

(Note 2)  $\overline{\text{SIGNAL INx}}$  input signal can be use general-purpose sensor function and synchronous start function.

If these signal is used, set the functions that need to be changed from their values.

The initial value after the relevant signal is reset is "No function" .

If this board is MANUAL mode, You can not use  $\overline{\text{SIGNAL INx}}$  input signal.

When this board is MANUAL mode, this signal(SEL A-D) enable to select an axis that perfoms MANUAL SCAN drive.

The functions assigned to the  $\overline{\text{SIGNAL INx}}$  input signal are invalid. And when this board returns to BUS mode, the functions assigned to this signal are valid.

(Note 3)  $\overline{\text{SIGNAL OUTx}}$  output signal can be output status signals of any axes by setting status output function.

The initial values after the relevant signal is reset are as follows:

$\overline{\text{SIGNAL OUT0}}$  is CNTINT signal of X axis.

$\overline{\text{SIGNAL OUT1}}$  is CNTINT signal of Y axis.

(Note 4) When this board is MANUAL mode,  $\overline{\text{SS0,SS1}}$  input signal(SEL A-D) enables general-purpose sensor that MANUAL SCAN drive specified axis.

When general-purpose sensor function is set as "UP/DOWN/CONST command", this input signal enable acceleration/deceleration command signal of MANUAL SCAN drive.

Pin No.	Di-rect-ion	Signal name	Description	
			BUS mode	MANUAL mode
1	-	D.GND	GND(internal +5V GND)	
2	In	MAN	MANUAL mode select signal (Note 1)	
3	In	FSSTOP	All axes immediate stop signal	
4	In	CWMS	Invalid	CW direction MANUAL SCAN drive command signal
5	In	CCWMS		CCW direction MANUAL SCAN drive command signal
6	-	D.GND	GND(internal +5V GND)	
7	In	SIGNAL IN0 / SEL A	General-purpose, synchronous start signal (Note 2)	The signals can be combined to select the axis used for manual operation.
8	In	SIGNAL IN1 / SEL B		
9	In	SEL C	Invalid	
10	In	SEL D		
11	Out	SIGNAL OUT0	(The initial value after resetting : XCNTINT)	
12	Out	SIGNAL OUT1	Staus output signal (Note 3) (The initial value after resetting : YCNTINT)	
13	Out	NC	Reserved	
14	Out	NC		
15	-	D.GND	GND(internal +5V GND)	
16	Out	+5V	Internal +5V	
17	In	SS0	Invalid	MANUAL SCAN drive acceleration/ deceleration command signal (General-purpse sensor signal) (Note 4)
18	In	SS1		
19	Out	MAN RDY	Permission signal switching MANUAL mode (Note 1)	
20	-	D.GND	GND(internal +5V GND)	

## 2-6. Input and Output Specifications

## (1) Output specifications

## Output specifications 1

Circuit	Description	
<p>Common for all axes</p>	Signal name	CWP, $\overline{\text{CWP}}$ , CCWP, $\overline{\text{CCWP}}$
	Output method	Line driver (differential) output (Equivalent to 26C31: Compliant with RS422A)
	Output current	$\pm 20\text{mA}$
	Output frequency	Maximum 6.5MHz(Independent drive)
	Insulation	Non-insulated

## Output specifications 2

Circuit	Description	
<p>Common for all axes</p>	Signal name	$\overline{\text{DRST}}$ (Can be connected from DRSTCOM to the +5V current limiting circuit: up to 15 mA)
	Interface voltage	+24V
	Output method	Nch transistor Open collector output
	Output current	ON :30mA(Vce = 1V or less) 50mA(Vce = 2V or less) OFF :0.1mA or less
	Output response time	1ms or less (ON OFF、OFF ON)
	Insulation	Photocoupler insulation (between internal circuits and external circuits)

## Output specifications 3(Applied function)

Circuit	Description	
<p>J3 connector signal</p>	Signal name	SIGNAL OUT0,1
	Interface voltage	+30V or less
	Output method	Open collector output
	Output current	ON :10mA(Vce = 0.6V or less) OFF :0.3mA or less
	Output response time	1 $\mu\text{s}$ or less (A latch and output time width can be set for output.) (ON OFF、OFF ON)
	Insulation	Non-insulated

(2) Input specifications

Input specifications 1

Circuit	Description	
	Signal name	$\overline{ORG}$ , $\overline{NORG}$ , $\overline{DEND/P0}$ , $\overline{SENSOR0,1}$ , $\overline{RESET}$ (A contact) $\overline{FSSTOPn}$ , $\overline{CWLM}$ , $\overline{CCWLM}$ (B contact)
	Interface voltage	+24V
	Input impedance	6.8K
	ON/OFF level	ON :2.5mA or more OFF :0.8mA or less
	Input response time	1ms or less (a signal other than the $\overline{RESETn}$ ) 5ms or less( $\overline{RESET}$ ) (ON OFF、OFF ON)
	Insulation	Photocoupler insulation (between internal circuits and external circuits)


Input specifications 2

Circuit	Description	
	Signal name	± ZORG
	Interface specifications	Line receiver input (should be connected to an RS422-compliant line driver)
	Input terminating resistor	220
	Response frequency	100KHz
	Insulation	Non-insulated

Input specifications 3 (Applied function)

Circuit	Description	
	Signal name	$\overline{MAN}$ , $\overline{CWMS}$ , $\overline{CCWMS}$ , $\overline{SS0}$ , $\overline{SS1}$ , $\overline{FSSTOP}$ $\overline{SIGNAL IN0,1 /SEL x}$
	Interface specifications	TTL level CMOS schmitt input
	Input level	High level open Low level 0.8V or less
	Input response time	5ms or less( $\overline{MAN}$ , $\overline{CWMS}$ , $\overline{CCWMS}$ ) 1ms or less( $\overline{SS0}$ , $\overline{SS1}$ , $\overline{FSSTOP}$ ) 10us or less( $\overline{SIGNAL INn0,n1 /SEL x}$ ) (ON OFF、OFF ON)
	Insulation	Non-insulated

2-7. Outside Dimensions



### 3 . SETTING

Before integrating the C-VX871E into the PC, set the switches on the board.


#### 3-1. Setting the Board Number(S1)

Assign a board number to the C-VX871E using the rotary switch S1 on the board.

(By default (before shipment from the factory), the rotary switch is board number 1)

When two or more C-VX871E boards are used, assign board numbers to the second and any subsequent boards in such a way that no numbers are duplicated.

The following figure shows an example in which board number 2 is assigned.




The S1 setting is validated after power-on.

Set the switch with power off, and turn it on after changing the setting.


## 4 . CONNECTION

### 4-1. Example of user I/O Interface Power Supply Connection



- For the user interface power supply (EXTV) of controller C-VX87E connect +24Vdc from the common power supply so that it turns on and off in synchronization with externally connected equipment.  
For easy connection, use the optional relay unit.
- For the power supply used for the driver interface(DRST signal), use one prepared by the controller, such as DRSTCOM.  
For details, refer to Section 4-2, "Examples of Connection to Drivers."


Power may be supplied to the driver from a power supply different from the C-VX871E such as by connecting to the DRST signal of the servo driver or motor free (MF) signal of the stepping driver. If so and power supply to the driver (+Vo) is greater than power supply to the C-VX871E (+V), leak current  $i$  flows through the protection diode of the output circuit and the input circuit of the connection destination may be put in the ON state.



## 4-2. Examples of Connection to Drivers


### (1) Example of connection to the stepping motor driver

(x axis pin numbers are used in this example.)



\*1 If the current limiting resistor on the driver side is less than 150  $\Omega$ , externally add resistor so that the total resistor value becomes 150  $\Omega$  or more.

\*2 When the input circuit uses a +24V interface, the connection is as follows:




\*3 The signal is connected when the encoder is used.

Example of connection refers to "Example of connection to the servo motor driver".


## (2) Examples of Connection to the servo motor driver

(X axis pin numbers are used in this sample.)




\*1 If the current limiting resistor on the driver side is less than 150  $\Omega$ , externally add resistor so that the total resistor value becomes 150  $\Omega$  or more.

\*2 When input circuit of the servo driver uses a +24V interface, the connection is as follows:



\*3 The signal is connected when the encoder signal is used.  
Connect the encoder signal to the line driver output circuit.

4-3. Examples of Connection to Sensor  
(1) Example of sensor attachment(photosensor)




Example of recommended sensors

Sensor that goes OFF upon receipt of light		Sensor that goes ON upon receipt of light		Remarks(Reference: Consumption current and type)
Maker	Rating	Maker	Rating	
SUNX	PM- 24	SUNX	PM- 24	15mA or less・NPN Type
	PM- 44		PM- 44	15mA or less・NPN Type
	PM- 54		PM- 54	15mA or less・NPN Type
	PM- 64		PM- 64	15mA or less・NPN Type
OMRON	EE-SX910R	OMRON	EE-SX910R	15mA or less・NPN Type

・ Please contact us, when you use sensors other than the above.  
(example: large 35mA article of consumption current etc.)

(2) Example of connection to a limit sensor

X axis pin number are used in this example.




- ・ The initial value of the limit signal is active-off (B contact) input.  
Even when the limit signal is not used, the limit signal input must be connected to GND in order to output pulses.
- \* Input logic of the limit signal can be switched. (Applied function)


### (3) Example of connection to an origin sensor

X axis pin numbers are used in this example.


#### When using the origin sensor only



#### When using the origin sensor+origin proximity signal




### When using the Z-phase signal of an encoder



### When using the P0 signal of stepping motor driver

Circular disk with a slit  
attached to the rotating shaft



## 5 . Maintenance



Incorrect handling may lead to an electric shock.  
Inspection and maintenance need to be conducted by an expert engineer only.  
Before inspecting and maintaining this product, turn off the power.



An electric shock, injuries, and fire may be caused.  
Do not make repair and modification such as product disassembly and parts replacement.

### 5-1. Maintenance and Inspection

#### (1) Cleaning method

To use the product in a favorable condition, conduct cycleic cleaning as follows.

- During the cleaning of the terminal plating part, wipe it with a dry, soft cloth.
- If stain is not removed by the dry wiping, soak a cloth in a solution in which neutral detergent is diluted, wring it out, and wipe off the stain with it.
- Do not use a high-volatile solvent such as benzene and thinner, and a wipe. This may deteriorate gold plating by transformation and oxidation.

#### (2) Inspection method

To use the product in a favorable condition, conduct periodic inspection.

Usually conduct the inspection every six months or every year.

To use the product in an extremely hot and humid or dusty environment, shorten the inspection interval.

Inspection item	Inspection details	Criteria	Inspection method
Environment state	Check whether ambient and intra-device temperatures are appropriate.	0 ~ + 45	Thermometer
	Check whether ambient and intra-device humidifies are appropriate.	10% ~ 80% RH(without dew condensation)	Hygrometer
	Check whether dust is deposited.	No dust	Visual check
Installation state	Check whether the product is firmly secured.	Not loose(6kg·cm)	Torque wrench
	Check whether connectors are completely inserted.	Not loose and removed	Visual check
	Check whether cables are to be removed.	Not loose and removed	Visual check
	Check whether connecting cables are to be broken.	Appearance is normal.	Visual check

#### (3) Replacement method

If the product becomes faulty, repair it immediately because the entire device system may be affected.

To make the repair smoothly, a spare product should be prepared.

- To prevent an accident such as an electric shock during replacement, stop the device and turn off the power.
- If poor contacting is assumed, wipe contacts with a clean cotton cloth that is wet with industrial alcohol.
- Take a record of switch settings during replacement and return them to their state before the replacement.
- After the replacement, confirm that the new product is normal.
- For the faulty product replaced, have it repaired by returning it to the company with a report indicating as much details on the failure as possible.

### 5-2. Saving and Disposal

#### (1) Saving method

Save the product in the following environment.

- Indoor (place in which the product is not in the path of direct sunlight)
- Place at ambient temperature and humidity within the specifications
- Place free of corrosive and inflammable gases
- Place free of dust, dirt, salt, and iron powder
- Place free of direct vibration and shock to the product body
- Place free of water, oil, and chemicals droplets
- Place where a person cannot ride or put objects on the product

#### (2) Disposal method

Handle the product as industrial waste.

## 6 . Conforming to Europe standards

### 6-1. Low Voltage Directive

The product does not cover low voltage directive on the conditions as follows:

The product is placed in the PC(Enclosure) declared CE marking.

And the control power of PCI bus is fed by the PC.

The power of the interface +24V is fed by the direct current power which primary and secondary are reinforced insulation.

A signal should interface using the motor drivers with which strengthening insulation of a primary side and the secondary side was carried out. Or a signal should interface between the motor drivers with which a primary and secondary side is supplied by the power supply by which strengthening insulation was carried out.

### 6-2. EMC Directive

The product declare CE marking based on EMC(2004/108/EC) Directive.

Please contact our company about E6 series cable when conforming CE Marking.

Applicable standards

EN61000-6-4

EN61000-6-2

EN61000-3-2

EN61000-3-3


The product is tested for EMC measurement by EMC measurement facilities.

EMC is changed by the equipment configuration including controllers and motor drivers.

Be sure to test EMC measurement in the condition installed in the final equipment.

## Configuration

The metallic enclosure (Metal Enclosure) and a metaled shielded cable (with a ferrite core) work to shield noise.



The main parts which revised by this manual

Parts	Content
None	

---

### **Technical Service**

TEL.(042)664-5382 FAX.(042)666-5664  
E-mail s-support@melec-inc.com

---

### **Sales and Service**

TEL.(042)664-5384 FAX.(042)666-2031  
URL:<http://www.melec-inc.com>

Melec Inc. Control equipment marketing department  
516-10,Higashiasakawa-cho,Hachioji-shi,Tokyo 193-0834,Japan